









INSTALLATION GUIDE

C301-4M/SS Cable Assembly **3mm CABLE SYSTEMS / CEILING-TO-FLOOR**

IMPORTANT: It is essential to check that the top ceiling fixings are strong enough to take the weight of the items being displayed while allowing for the tension in the cables.

- 1) Affix fitting (A) to ceiling:
- for wood stud walls use a wood screw. - for cavity/plaster wall use a spring toggle bolt (this
- option needs to be tested).
- for solid/concrete wall use a raw-plug and screw.
- 2) Screw fitting (B) to fitting (A).
- 3) Using a plumb-line, descend from (A), and fix (F) to floor using appropriate type of fixing.
- 4) Loosen the grub screws in fitting (E), using the Allen key provided, and slide fittings (C), (D), and (E) up the cable.
- 5) Pull down and cut off excess cable as per diagram.
- 6) Tighten (E) on the end of the cable.
- 7) Adjust the tension of the cable by screwing (C) into (F).
- **8)** Attach the panel and shelf support fittings onto the cables, space them out and secure at the desired position.
- 9) Attach panel and shelf accessories.

NOTE: It is important to check the strength of all fixings. NOVA DISPLAY SYSTEMS takes no responsibility for incorrect installation. This responsibility rests with the installer. Cables are not supplied with fixing screws.

*** DO NOT INSTALL INTO PLASTERBOARD (DRYWALL) WALLS IF YOUR APPLICATION **INCLUDES GLASS SHELVES OR OTHER HEAVY** ITEMS.

